


NORITA



Reprinted February 1976

© Copyright 1973



National Camera
Technical Training Division
Englewood, Colorado, 80110 U.S.A.

All rights reserved.



LEFT-SIDE
PRISM LOCK

SYNC TERMINAL

120-220 SELECTOR

N-D
COUNTER
RELEASE

BACK SAFETY
LATCH

MAIN BACK LATCH


LENS-LOCKING RING


1. REMOVE PRISM
AND LENS


2. OPEN BACK


2
















7

SHUTTER COCKED



8





COCKING CAM

LOOSEN SETSCREW AND LIFT
OFF SPEED KNOB



10





1. UNSCREW TOP-COVER RETAINING RING

2. REMOVE TWO TOP-COVER
RETAINING SCREWS





1. PULL UP SUPPLY-SPOOL TRUNNION


3. UNSCREW TRUNNION


2. WEDGE TRUNNION SHAFT


14

















N-D SHAFT PASSES THROUGH SPACE BETWEEN
THESE TWO LEVERS


TO OPERATE CAMERA, REPLACE N-D SHAFT
WITH BEARING PLATE AND N-D SELECTOR--
ALSO, REPLACE WIND LEVER





20

























29

REMOVE THREE SCREWS AND LIFT OFF
WIND-CAM PLATE




30


CAUTION: WATCH FOR LOOSE BALL BEARINGS
AS YOU REMOVE MAIN-WIND ASSEMBLY



LIFT OFF LOWER RATCHET PLATE





32





33

1. COCK SHUTTER












37












41




REMOVE TWO SHOULDER SCREWS AND LIFT OUT
MAIN-RELEASE SLIDE






1. REMOVE SCREW HOLDING DIAPHRAGM-CLOSING-LEVER SPRING

2. LIFT OUT DIAPHRAGM-CLOSING LEVER




REMOVE SCREW AND LIFT OFF
OPENING-CURTAIN CAM


45



UNSCREW RETAINING RING (LEFT-HAND
THREAD) AND LIFT OFF MAIN-
TRANSPORT CAM

46






48


120-220 CONTROL LEVER

1. REMOVE SCREW AND LIFT OFF COUNTER DIAL (RETURN SPRING IS UNDERNEATH COUNTER DIAL)





1. LIFT OUT COUNTER-DISENGAGING
LEVER


2. REMOVE TWO SCREWS AND LIFT
OUT COUNTER-CONTROL ASSEMBLY





50



















1. HOLD OPENING-CURTAIN TAKE-UP ROLLER AND
UNSCREW SYNC-DRIVE GEAR





2. REMOVE TWO SCREWS AND LIFT OFF OPENING-
CURTAIN-TAKE-UP-ROLLER BEARING PLATE




2. LIFT OFF SPRING AND UPPER SECTION OF OPENING-CURTAIN LATCH - - PULL OUT LOWER SECTION OF OPENING-CURTAIN LATCH TOWARD BOTTOM OF CAMERA.

1. REMOVE SCREW HOLDING UPPER SECTION OF OPENING-CURTAIN LATCH








1. REMOVE TWO SCREWS HOLDING GUIDE-ROLLER
BEARING PLATE - - LIFT OUT BEARING
PLATE AND GUIDE ROLLER

2. REMOVE TWO SCREWS HOLDING OPENING-
CURTAIN WINDING ROLLER



3. REMOVE TWO SCREWS HOLDING CLOSING-
CURTAIN WINDING ROLLER

63